



- 1) Loosen the handle grub screws and remove grip A.
- 2) Separate the handle assembly.
- 3) With the gaskets in place, install grip B onto the door.
- 4) Install grip A, ensuring the grub screws are not facing upwards.