

INSTALLATION INSTRUCTIONS



SHOWER

ACRYLIC SHOWER TRAY WITH TILED WALL



PLEASE FOLLOW THESE GUIDELINES WHEN INSTALLING TILED WALLS WITH YOUR ENGLEFIELD SHOWER TRAY AND DOOR.

IF IN DOUBT, CALL OUR AFTER-SALES SERVICE TEAM FOR GUIDANCE.

1. Discuss the installation and tiling with your chosen waterproofing / tiling professional and Approved Englefield Installer prior to starting.
2. Follow both the Englefield Acrylic Shower Tray and wall board manufacturer (eg. GIB®, Villaboard® or other) instructions when installing the shower tray and wall board.
3. If possible, the complete door system should be installed onto the cured waterproof membrane prior to wall tiling.

AT A MINIMUM THE VERTICAL WALL RETAINER EXTRUSIONS MUST BE INSTALLED ONTO THE CURED WET AREA MEMBRANE PRIOR TO WALL TILING.

Failure to do so may mean that the door system may not fit on the shower tray due to a combination of tile thickness, tile adhesive thickness and any positive / negative inclination of the finished wall board.

PLEASE REFER TO SHOWER DOOR INSTALLATION INSTRUCTIONS FOR ANY TILE CLEARANCES THAT NEED TO BE OBSERVED.

4. Fill any screw holes that penetrate the waterproof membrane with silicone sealant. Defer to any further recommendations of your chosen waterproofing / tiling professional regarding this.

CONTACT INFORMATION

NEW ZEALAND
KOHLER NZ LTD

Free Ph: 0800 100 382
Free Fax: 0800 664 488
www.Englefield.co.nz

AUSTRALIA
KOHLER CO.

Free Ph: 1 800 ENGLEFIELD
(1 800 364 533)
www.Englefield.com