


## CLEANING AND MAINTENANCE INSTRUCTIONS

(a) Gently prise waste lid assembly from lock ring in shower base.



(b) Remove any obstruction then wipe clean.



(c) Replace and rotate waste lid until it snaps into place.



Instructions, drawings, and diagrams contained in this manual present information available at the time of printing. Although every attempt has been made to keep them up-to-date, Englefield reserves the right to implement product changes without further notice.

## CONTACT AND WARRANTY INFORMATION

**NEW ZEALAND**  
KOHLER NZ LTD

Free Ph: 0800 100 382  
Free Fax: 0800 664 488  
[www.engagefield.co.nz](http://www.engagefield.co.nz)

**AUSTRALIA**  
KOHLER CO.

Free Ph: 1 800 228 476  
[www.engagefield.com](http://www.engagefield.com)

**For warranty information, please visit our website**



Trusted in New Zealand Since 1982

INSTALLATION  
INSTRUCTIONS

Trusted in New Zealand Since 1982

## SHOWER



Englefield has a history of making superb showers and their popularity is testament to their quality and affordability.

It's the details that Englefield cares about - from pioneering the latest technology, to innovative design, it's all to make your showering experience the very best it can be.

## HI FLOW WASTE



## BEFORE YOU BEGIN


Before installing please read these instructions carefully to familiarise yourself with the required tools, materials and installation sequences. Please leave these instructions for the consumer after installation.

**! IMPORTANT**

It is recommended that the **HI FLOW WASTE** is fitted to the shower tray prior to installation.


All installation must comply with council and local authority by-laws. It is the responsibility of the installer to ensure that the waste is made watertight.

## ROUGH-IN




## INSTALLATION

(a) Align fingers on adapter with slots in waste lid, then snap fit together.




(b) Ensure lock ring seal is correctly fitted.



(c) Fit Hi Flow Waste to shower tray. Use lock ring tool to tighten lock ring against 'H' ring and waste body.

Remove lock ring tool before snap fitting waste lid.



## SPARE PARTS

